

JUNIOR WRAPAROUND™

JUNIOR RANGE - BLACK FRAME - CLEAR LENS

TECHNICAL SPECIFICATION

ONE PIECE LENS, CAN BE WORN OVER PRESCRIPTION EYEWEAR

EYE & FACE PROTECTION

INSTRUCTIONS FOR USE

In use ensure that the safety spectacles fit comfortably and securely on the head

Ensure that the safety spectacles are in place, before entering the hazard area

DIMENSIONS OF SPECTACLE

Lens Thickness: 2.2mm

Weight: 0.06kg (Approx.)

Frame: ..
Nylon 66 A60



Lens:
Polycarbonate

PERFORMANCE

Wraparound eyeshield for wide vision and complete protection

Horizontal adjustable side arms for perfect fit

Can be worn over prescription eyewear

Lens and body offer protection against low energy medium-speed particles at 45m/s.

The optical qualities of the lens comply with the requirements of optical class 1 (highest).

LIMITATIONS OF USE

Protection will only be offered if the safety spectacles are fitted correctly

If the safety spectacles become scratched or damaged they should be replaced, likewise if the safety spectacles are subjected to severe impact they should be replaced immediately

Do not apply paint, solvents, adhesives or self-adhesive labels, except in accordance with instructions from the manufacturer

The safety spectacles, when in contact with the skin may cause allergic reactions to susceptible individuals. If this occurs leave the hazard area, remove the eye shield and seek medical advice

The attention of users is also drawn to the dangers of modifying or removing any of the original component parts, other than as recommended by the manufacturer

CONFORMITY

Conforms to EN 1661.F & EN 170

EC Certificate Number 409, issued by Inspec Certification Ltd

MARKINGS

Body: EN166

Lens: EN166

1 . F ↑

CLEANING & MAINTENANCE

The safety spectacles may be cleaned with soap and warm water and dried with a soft cloth

Do not clean with chemical or abrasive cleaners

The eye shield should be stored out of direct sunlight, away from chemicals and not exposed to extremes of temperature